

KOLPIN[®]

OUTDOORS

21500 – Rhino Grip

21505 - Rhino Grip Double

Rhino Grips are designed to quickly and easily mount to an ATV or UTV by securing the Rhino Grips to the vehicle with the provided metal back plate and hardware.



21500

21505

Mounting Instructions

1. Position the Rhino Grip on the roll bar / rack in the desired location.
2. Place the rubber strip between the bottom side of the Rhino Grip and the roll bar / rack. The rubber strip is supplied to help keep the Rhino Grip from rotating on the bar / rack.
3. Place the metal plate on the backside of the bar / rack aligned with the hole pattern on the Rhino Grip.
4. Run the Qty (4) ¼" bolts through the Rhino Grip and the metal backer plate. Assemble with the (4) nylon nuts.
5. Tighten the (4) ¼"-20 bolts evenly. Note: Be sure not to over tighten the bolts, as too much torque can over stress the base and cause the grip to fail.

Instructions for Use

1. Place the object you would like to secure / transport in the Rhino Grip. Assemble the rubber strap into one of the (3) three positions on the Rhino Grip that will best hold your object. Pull the strap over to the opposite side and secure in one of the (3) three positions that best secures the object.
2. Additional straps, Part Number 87010, are available by contacting Kolpin.

Thank you for purchasing Kolpin products! If you need additional assistance, please contact our technical service team by phone or e-mail.

Kolpin Outdoors, Inc.
 Telephone: (763)-478-5800
 Toll Free: (877)-956-5746
 www.kolpin.com
 Email: customerservice@kolpin.com